

Document No.		Issue:	
Authorised by:		Authorised Date:	
Procedure:			
Title:			

SEMI-RIGID GUIDEPOST INSTALLATION

To install semi-rigid using our pneumatic post driver:

Step	Process
Step 1	Fit the dolly onto the post. Lay the post and ergonomic driver on the ground in desired position and slide the post and dolly into the pneumatic driver.
Step 2	Connect the air hose to driver and compressor. Ergonomically lift the driver and post carefully to vertical.
Step 3	Place your foot against the bottom of the post (post shown in side view) to hold straight and levelled.
Step 4	Drive the post into the ground letting the weight of the driver do the work – not your back. Press the lever to start driving the post into the ground. Continue driving until the depth mark slot is at ground level. It is important that the post is driven in this far for the post to function properly and be firmly anchored into the ground.
Step 5	Keeping your arms slightly extended and your head and face away from the driver, carefully remove the driver from the post.
Step 6	Check for a secure installation and satisfactory post function by attempting to bend the post back and forth. If the post is loose, the ground may be too soft in which case the ground surrounding the post should be compacted.

Note: Compressor must be a minimum of 35cfm (11hp) and 1/2" or 12mm unrestricted hose minimum hose size is required. Delnorth recommends wearing appropriate PPE including safety goggles and hearing protection while installing posts. Delnorth does not recommend digging the post in. In extremely hard ground, the use of a mechanical Driver may be beneficial. (Please see mechanical Driver Instructions).

