


Document No.		Issue:	
Authorised by:		Authorised Date:	
Procedure:			
Title:			

3MM, 4MM, AND 5MM UPVC GUIDEPOST INSTALLATION

Delnorth Plastic Guidepost is a unique Australian made flexible delineated guidepost which is installed using a posthole borer or Delnorth Installation Driving Kit. It is capable of withstanding repeated impacts by vehicles in both directions with minimal damage to the post or vehicle.

Step	Process	Safety Precautions
		<p>Delnorth recommends wearing appropriate PPE including safety goggles and hearing protection while installing posts. Delnorth does not recommend digging the post in.</p> 
Step 1	Utilising a mechanical or manual auger, dig hole in accordance to relevant specification position.	
Step 2	Place post at 90° to road edge facing oncoming traffic.	
Step 3	Replace extracted ground filling and compact firmly to secure post to a density that is not less than that of the adjacent undisturbed ground.	
Step 4	Keeping your arms slightly extended and your head and face away from the compactor whilst operating apparatus.	
Step 5	Check for a secure installation and satisfactory post function by slowly bend the post back and forth. If the post is loose, the ground may be too soft in which case the ground surrounding the post should be compacted again.	

(N.B. UPVC guidepost can be driven from the top of post utilizing our manual driver in soft ground)

